
For Models: KUWS246EWH02, KUWS246EBL02, KUWS246EBT02, KUWS246ESS02 (White) (Black) (Biscuit) (Stainless Steel)



## **CABINET PARTS**

For Models: KUWS246EWH02, KUWS246EBL02, KUWS246EBT02, KUWS246ESS02 (White) (Black) (Biscuit) (Stainless Steel)

| Illus.<br>No. | Part<br>No. | DESCRIPTION       | Illus.<br>No. | Part<br>No. | DESCRIPTION       | Illus.               |            | DESCRIPTION        |
|---------------|-------------|-------------------|---------------|-------------|-------------------|----------------------|------------|--------------------|
| NO.           | NO.         | DESCRIPTION       | <u>NO.</u>    | NO.         | DESCRIPTION       | -   <del>- NO.</del> | No.        | DESCRIPTION        |
| 1             |             | Cabinet (Not A    | 14            |             | Hinge, Bottom     | 25                   | 4344630    |                    |
|               |             | Serviceable Part) |               | 4344642     | White             | 26                   |            | Fan Motor          |
| 2             |             | Grille            |               | 4344643     | Black             | 27                   |            | Fan Blade          |
|               | 4344603     | White             |               | 4344648     | Biscuit           | 28                   |            | Power Cord         |
|               | 4344604     | Black             |               | 4344652     | Stainless         | 29                   | 4344634    | Evaporator And     |
|               | 4344644     | Biscuit           | 15            |             | Door Gasket       |                      |            | Heat Exchanger     |
| 3             |             | Wine Shelf        |               | 4344618     | White             | 30                   |            | Leveler Feet       |
|               | 4344656     | White             |               | 4344639     | Grey              | 31                   | 4344636    | Lock (Includes     |
|               | 4344657     | Chrome            | 16            |             | Door Handle       |                      |            | Key)               |
| 4             | 4344606     | Condenser         |               | 4344654     | White             | 32                   | 4344638    |                    |
| 5             | 4344607     | Door Switch       |               | 4344653     | Black             | 33                   | 4344637    |                    |
| 6             | 4344659     | Thermostat        |               | 4344646     | Biscuit           | 34                   |            | Nameplate          |
|               |             | (Includes #7)     |               | 4344650     | Stainless         |                      | 2205367    |                    |
| 7             |             | Knob, Thermostat  | 17            | 4344621     | Compressor        |                      |            | Biscuit Models     |
|               |             | (Not Available    |               |             | (Includes Items   |                      | 2205369    | Black and          |
|               |             | Order #6)         |               |             | 22, 25 & 32)      |                      |            | Stainless Steel    |
| 8             |             | Light Bulb        | 18            | 4344622     | Glass Shelf, Half |                      |            | Models             |
| 9             | 4344660     | Shelf Clip        | 19            |             | Door Assembly     |                      |            |                    |
| 10            | 4344611     | Drain Cup         |               |             | (Includes Items   | l                    |            |                    |
| 11            | 4344655     | Drain Pan         |               |             | 15, 16 & 31)      | REF                  | RIGERA     | NT CHARGE          |
| 12            | 4344613     | Drain Through     |               | 4344623     | White             |                      |            |                    |
| 13            |             | Hinge, Top        |               | 4344624     | Black             |                      |            | 3.0 oz.            |
|               | 4344640     | White             |               | 4344645     | Biscuit           |                      |            | (R-134A)           |
|               | 4344641     | Black             |               | 4344649     | Stainless         |                      |            |                    |
|               | 4344647     | Biscuit           | 20            |             | Light Switch      | LITE                 | RATURE     | PARTS              |
|               | 4344651     | Stainless         | 21            | 4344626     | Light Socket      | =:-=                 |            | <u> </u>           |
|               |             |                   | 22            |             | Overload          |                      | LIT4344600 | Use & Care Guide   |
|               |             |                   | 23            |             | Back Panel        |                      | LIT4344601 | Installation Guide |
|               |             |                   | 24            | 4344629     | Light Cover       |                      |            |                    |

